


2 x 10W Max LED E14 SES (required)
Non-dimmable
FCL-32596X2



Cleaning Instructions

Please note a small trace of oil is used to protect the tiffany surface during the manufacturing process. Best care is taken to ensure any excess residue is removed after production.

To clean the fixture use a soft microfiber cloth dampened with a mild solution of dish soap and warm water. Wipe the glass gently, avoid soaking the solder lines, and dry immediately with a clean, lint-free cloth.